

IT133 - Phantom Mini Charger Key Chain



ITE: Accessories Lithium ion battery UL 2056 certified

Model: SP0301
Item No.: IT133
Input: DC 5V/1000mA
Maximum input: DC 5.3V/1000mA
Output: DC 5V/1000mA
Battery/Cell capacity: 3.7Wh, 3.7V / 1000mAh
Product capacity: 2.5Wh , 5V / 500mAh
Operating temperature: 0~45°C for Charging
0~50°C for Discharging

Product Name: Power Bank

EN


CAUTION: Risk of Fire and Burns, don't open, crush, disassemble and dispose of in fire. Accessible surfaces held or touched for short periods only. Don't heat above 50 °C or Incinerate. Follow Manufacturer's Instructions

FR

DANGER: risque d'incendie et de brûlures, ne pas ouvrir, démonter, écraser ni jeter au feu. Ne pas toucher ou tenir les surfaces accessibles sur une longue durée. Ne pas chauffer au-dessus de 50 ° C. Instructions de fabricant Suivre

MADE IN CHINA

PRODUCT OVERVIEW



1. 5V Input Port (Micro USB)
2. 5V Output Port (USB A-type)
3. LED indicator

Indicator

Status	LED Indicator
Charging	Red(Flash)
Fully charged	Red
Working	Blue

Accessory: USB Cable



USB CABLE

How to use

Instructions:

1. Charging the portable Power bank.

a. Connect a USB charging cable to your phone's USB adapter. Using the Micro USB connector, connect the other end of the USB cable into the IN port on the portable Power bank. Then plug the USB adapter into the outlet to begin charging.

b. Using your computer. Connect a USB cable to a USB port on your computer. Using the Micro USB connector, insert the other end of the USB cable to an IN port of the portable Power Bank. Make sure the computer is on to begin charging the portable Power bank.

2. Charging smartphones and other electronic devices.

a. The portable power bank has a USB output port which has the maximum output current of 1000mA.

b. Connect a USB charging cable to your smartphone/device using the appropriate connector. Insert the other end of the USB cable to the OUT port of the portable Power bank. Your mobile smartphone/device should display the status of charging.

c. Remove the USB cable from your mobile device when it is fully charged.

Note: In order to charge device use only accessory cable (included with power bank) or the cable included with your own device by the manufacturer.

IMPORTANT SAFETY PRECAUTIONS

WARNING - When using this product, basic precautions should always be followed, including the following:

1. Read all the instructions before using the product.
2. Power bank main unit contains an internal lithium ion battery. Full charge power bank prior to initial use and after a prolonged storage period. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles.
3. Power banks are not allowed in checked luggage on commercial airline flights. Handle with care and dispose of in accordance to local regulations. Carry-on only.
4. To reduce the risk of injury, close supervision is necessary - when the product is used near children.
5. Do not put fingers or hands into the product.
6. Do not expose power bank to rain or snow.
7. Use of a power supply or charger not recommended or sold by power pack manufacturer may result in a risk of fire or injury to persons.

8. Do not use the power bank in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury to persons.

9. Do not use the power bank that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.

10. Do not disassemble the power bank. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury to persons.

11. Do not expose a power pack to fire or excessive temperature. Exposure to fire or temperature above 100°C may cause explosion. The temperature of 100°C can be replaced by the temperature of 212°F.

12. Have servicing performed by a qualified repair person using only identical replacement parts. This will ensure that the safety of the product is maintained.

13. Do not charge the power bank while using the power bank to charge a device. Do not charge the power bank for more than 4-6 hours and do not leave unattended.

14. Disconnect the power bank when not in use.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



www.primeline.com

Copyright